Power-Out & No-Wi-Fi Alert Kit

Setup guide · While You're Away Co. · homewatchtreasurecoast.com

What's in your kit

Device	Qty	Where it goes
YoLink Hub 3 (YS1605), cellular-ready, with backup battery	1	Central spot, indoors, on a wall outlet. Near a window helps the LTE signal.
YoLink Power Fail Alarm (YS7106), 2 AA backup batteries installed	1	Plugged into an outlet on the circuit you want watched (for example, the one the refrigerator or A/C air handler closet uses).
YoLink Water Leak Sensor 4 (YS7906)	3	On the floor by the water heater, the A/C air handler and the washer or kitchen sink.
YoLink Temperature & Humidity Sensor (YS8003)	1	Main living area, away from vents and direct sun.

Parts ship from our fulfillment partner and may arrive in more than one box. Keep each device's own quick-start card. YoLink's manuals are the final word on every device.

1. Set up the hub (about 10 minutes)

1. Install the free YoLink app and create an account.
2. Plug the Hub 3 into power. For the easiest setup, also connect the included Ethernet cable to your router. YoLink says the hub uses Ethernet first, then 2.4 GHz Wi-Fi, then cellular.
3. In the app, tap + and scan the QR code on the hub.

2. Decide on cellular service

Cellular service is a separate YoLink subscription, paid to YoLink, not to us. It costs $6.99 a month (YoLink also sells an $83.88 annual plan). To start it, tap the hub in the app, then the LTE package icon, and follow the subscription screen. When service is active, the hub's LTE icon turns green.

Without a plan, the hub works over Wi-Fi or Ethernet like any YoLink hub, and phone alerts stop whenever the home's internet is off.

YoLink's Hub 3 manual recommends cellular as the backup connection in a home power or internet outage. It also says the hub's rechargeable battery keeps it working for about 4 to 8 hours when the power goes out.

3. Add the sensors (about 15 minutes)

1. Tap + in the app and scan each device's QR code. Name them by location ("Water heater leak", "Kitchen power").
2. Power Fail Alarm: plug its adapter into the outlet you want watched and connect the Micro-USB cable. The AA batteries run it when the power drops, and USB power does not recharge them, so replace them as YoLink directs.
3. Leak sensors: set flat on the floor where water would collect first.
4. Temperature & humidity sensor: set alert limits in the app. Many Florida owners use a humidity alert at 60%, matching the EPA's guidance to keep indoor humidity below 60%.

4. Turn on the right alerts

- For each device, open its alarm settings and choose push, email and text alerts.
- **Hub offline alert:** Hub > Device Details > View your alarm strategies > + > select the hub > choose notifications. This tells you if the hub drops offline, for example after its backup battery runs down in a long outage.
- Share the home with a family member or neighbor in the app so more than one phone gets alerts.

5. Test before you leave

1. Touch a damp paper towel to a leak sensor's probes. You should hear the alarm and get an app alert.
2. Unplug the Power Fail Alarm's adapter. It should sound and you should get a power-loss alert. Plug it back in.
3. If you have a cellular plan, unplug the router for a few minutes and repeat test 1. The alert should still arrive over cellular.

Good to know: This kit alerts you. It does not restore power, start a generator, shut off water or call anyone. Have someone local who can get inside, and decide in advance what they should do if an alert comes in.

© 2026 While You're Away Co. (Martin County Home Watch LLC) · Stuart, FL · homewatchtreasurecoast.com · hello@homewatchtreasurecoast.com. General information only. Follow YoLink's instructions for each device. Device models may

be substituted with comparable ones if unavailable. Sources: YoLink Hub 3 (YS1605) Installation & User Guide; YoLink Power Fail Alarm (YS7106) product page and help center; EPA "A Brief Guide to Mold, Moisture and Your Home."